

# 4iiii

## Frame Clearance Check for 4iiii PRECISION 3 Powermeter

### What you need:


- Printer
- Letter size Paper (8 ½" x 11")
- Scissors
- Tape
- 8mm Allen/Hex wrench

### Let's get started!

1. Make sure the crank arm on your bike is compatible with 4iiii powermeters. For a list of compatible cranks, go to <https://4iiii.com/crank-finder>
2. Print this page on letter size paper and cut out the diagram of the Frame Clearance Checker
3. Using a ruler, confirm the Frame Clearance Checker is the correct size indicated on the scale (A to B is 10 cm / 4").
4. Position your left crank arm so that it is aligned to the chainstay shown in photo below
5. Fold the Frame Clearance Checker along the dashed line.
6. Place the Frame Clearance Checker on your crank and align the folded crease with the edge of your crank arm as shown in photo below



### Frame Clearance Checker





## Frame Clearance Check for 4iiii PRECISION 3 Powermeter

---

7. Holding the 8mm allen/hex wrench vertically, slide it between the crank arm and the frame/chainstay along the grey region of the Frame Clearance Checker as shown in the photo.
8. If the 8mm allen/hex wrench can slide easily along the grey region, your bike is compatible with a Ride Ready PRECISION 3 powermeter.
- ★ If the 8mm allen/hex wrench contacts the frame at any point in the grey zone, contact our team to explore Factory Install options.
  - [What is a Factory Install?](#)

Need additional help?

Go to [4iiii.com/support](https://4iiii.com/support) for our FAQ's and to contact our Customer Support Team

